



Boom 2 Compressor Mount

Note: Remove the right-side saddlebag before starting this procedure.

1. Install the compressor onto the Boom 2 mount as shown.



2. Remove the two bolts from the rear of the saddlebag mount rail. Install the Boom 2 compressor mount onto the bag rail, using the provided bolts and the factory nuts.

