

Center Stand Safety Hit

Note: Empty all air out of the shocks before starting this procedure.

 Using the provided 5/32" airline, connect the side of the safety tee with two fittings to existing airline fittings.



 Mount the provided mechanical valve switch in your preferred location. (We use the firewall switch plate available on our website, as shown.)



То

shocks

 Connect the end of the safety tee with a single fitting to the mechanical valve switch with the 5/32" airline.

