



## Gen 2 Compressor Mount

### Installation

1. Remove right side saddle bag.

2. Remove all three bolts from both clamps.



3. Place the two larger halves of the clamps onto the compressor by sliding them on from the top.



4. While holding the compressor and clamp halves in place on the saddlebag support rail, put one of the smaller halves in place, insert the long bolt into the middle hole and tighten on the nut. Repeat for the second clamp.



5. Ensure the position of the compressor clears the saddlebag and brake rotor, then tighten the remaining clamp bolts.

